
# Laser Cutting/ Engraving System



## **Introduction to Laser Cutting**

A laser is a device that emits light through an optical amplification process through the stimulated emission of electromagnetic radiation

Laser cutting is a method which uses a CAD file to guide it and precisely cut a design

3 main types of lasers used in the industry are: CO2, Fiber, Neodymium Examples of Laser Cut Products:



Phone Case



Laser Cut Bag



Decorative Lamp




Paper Cut

## **Laser Cutting/ Engraving Materials**

ecommended Material	No-no Material
Acrylic	Highly Flammable Material
Wood (Plywood)	Corrugated Cardboard
Cardboard (Greyboard/Bristol	Reflective Material
Board/Paper)	Glass
	Metal
commended Material	• Stone
ickness Range: < 6mm	<ul> <li>PVC (cutting PVC releases extremely</li> </ul>
	toxic fumes)
	• Foam
	Styrene (primarily used in the
	production of polystyrene plastics ar
	resins)

# Laser Cutting/ Engraving System Overview



#### Specifications:

Overall Dimension (W x L x H): 1365 x 880 x 1010 mm

Work Area: 960 x 610mm

Engraving Capability: 256-level gray scale image processing capability

Safety: Class I Laser Product Compliant with EN60825

Laser Source: 80W 10.6-µm sealed CO2 Laser

# Laser Cutting/ Engraving System Operation


1. File Preparation

2. Machine Preparation

3. Machine Operation

S/N	Procedure	Pictorial Aid
1	Open CorelDraw X7 from Desktop	
2	Click on the "New Document" Icon (Located on the Welcome Screen to create new document)	New Document
3	Check if parameters are the same as image (If not, change parameters according to image)	SpiritGLS Ext
4	Import your prepared file for laser cutting/ engraving (File format must be DWG, DXF or AI)	File Edit View Layou  New Acquire Image  Search Content  Import
5	Position and drop imported file  (Drop at the Top Left corner of blank sheet, advisable to leave at least 3mm gap on each side for a clean cut)	SpiritGLS Ext 960.0 mm
6	Select LINE(s) to cut and double click icon (Icon located at the bottom of the screen)	№ R:255 G:0 B:0 (#FF0000)
7	Select "Hairline" as line weight for cutting	Color:  Width:  Hairline  None  Hairline  O 1 mm

8	Click on " <b>More</b> " at the Color pull down tab  Select " <b>RGB</b> " in the pull down tab after popup appears	Color: Width: Hairline Style:  Models  Mixers  Palettes  Model: RGB  CMY CMYK RGB HSB
9	Change colour to <i>Red (R-255, G-0, B-0)</i> for cutting	R 0
10	Select AREA(s) or LINE(s) to engrave and double click either icons (Icons located at the bottom of the screen)	None Fill  R:255 G:0 B:0 (#FF0000) Outline
11	Click "Uniform Fill" to fill area  Select "Hairline" as line weight for engraving lines	Color:  Width:  Hairline  None  Hairline  0.1 mm
	Change colour to <i>Black (R-0, G-0, B-0)</i> for	



S/N	Procedure	Pictorial Aid
17	Set " <b>Home</b> " for Position Mode under the Advance Tab	stion Pen Advance Paper Langua Scaling X:
18	Select " <b>Extend</b> " under the Paper Tab  (Ensure that paper size is 960 x 610mm)	Paper Size  X: 960.00 mm  Extend Y: 610.00 mm
19	Check the Preview before transferring file to machine  Click "OK"	Print to file  Print to file  Copies  Number of copies  I grade  Contate  Contate  Print as bitmaps  Size & Augoby  Help

S/N	Procedure	Pictorial Aid
1	Place material onto the Laser Table (Align to the Top Left Corner)	
2	Lightly pull Laser Head towards you (Bringing it closer to you will enable better accessibility during set-up of Laser Table Z-Height setting)	
3	Place Manual Probe into the Laser Head Slot to start setting the Z-Height of the laser table	
4	Press the <b>UP</b> or <b>DOWN</b> arrows on the Display Panel to raise or lower Laser Table	Estimatives  Disease 76 Boltz   Sass  Disease 78 Boltz   708  Disease 78 Boltz
5	Bring the tip of the probe to just touch the material surface by repeating step 3 (Leaving no gap between probe and top surface of material and no gap between probe and laser head slot)  *Remove manual probe when completed	
6	Return Laser Head to Home Position by pressing onto <b>F4</b> twice on the Display Panel  • Function – F4	Door Power  BZ!UnEITIed—1 Speed: 75.0%DPI: 508 Power: 58.8%PPI: 708

Procedure	Pictorial Aid
Check if print job is correct, or else, press <b>F1</b> or <b>F2</b> to scroll and find the correct job	BZRIMETEIGA  Power Selection  Power Function  Power Function  From Next Func  Function  Function
Press the " <b>Start/Stop</b> " button on the Display Panel with the Laser Lid open to do a test run. Check if tracing path is correct.	Cot
Press the " <b>Start/Stop</b> " button again to stop test run if tracing is satisfactory and close the Laser Lid	A STATE OF THE PARTY OF THE PAR
Switch the laser on by inserting and turning the key to the " <b>ON</b> " position	
Press the "Start/ Stop" button to begin printing  **DO NOT LEAVE MACHINE UNATTENDED WHILE PRINTING**	1 (2 (2 (4 (4 (4 (4 (4 (4 (4 (4 (4 (4 (4 (4 (4
Press <b>F1</b> to pause and press <b>F1</b> again to resume  To completely stop printing, press the "Start/Stop" button	Power    Control   Control
	Check if print job is correct, or else, press F1 or F2 to scroll and find the correct job  Press the "Start/Stop" button on the Display Panel with the Laser Lid open to do a test run. Check if tracing path is correct.  Press the "Start/Stop" button again to stop test run if tracing is satisfactory and close the Laser Lid  Switch the laser on by inserting and turning the key to the "ON" position  Press the "Start/ Stop" button to begin printing  DO NOT LEAVE MACHINE UNATTENDED WHILE PRINTING  Press F1 to pause and press F1 again to resume  To completely stop printing, press the "Start/

Laser Cutting/ Engraving System Guidelines



## **Rules & Regulations**

Limited to *one laser machine per user* 

Please *sign in* to the logbook before you start

Failure to show up or cancel your booking may result in the suspension of your booking privileges


**Booking is for individual and not transferable** as every student is allocated equal timeslots based on total students capacity from all faculty

FabLAB Facilities are for authorised SUTD personnel only

A standing fan is not allowed inside the laser section

# **Operating Hours & Bookings**

- Monday to Friday, 9am to 5pm
- Closed on Public Holidays



Please book laser machine on:

https://edbyo.sutd.edu.sg/edsystems/index.html



# **Safety Guidelines**

After cutting your material, *wait 1-2 minutes* before opening the laser lid so that the fumes disperse

Do not cut your material on top of the laser lid.



3. To avoid retinal damage, **do not stare at the** laser beam.



- 4. If you see *repeated flames while cutting, stop* the laser cutter and adjust your settings.
- Never leave the laser machine unattended while it is running





6. Laser cutting has *HIGH RISK OF FIRE*. Be Alert!




7. In the event of a fire, there is a *fire*extinguisher located inside the laser section



8. If the O<sub>2</sub>/CO<sub>2</sub> alarm sounds, all work must stop and *evacuate the room immediately* 





Please check notices outside Laser Section



Wearing a mask is dependent on IAQ Level

ANNOUNCEMENT
LASER SECTION
IAQ LEVEL: Normal


\*Mask (surgical type) will be issued upon request only

IAQ NOTICE

LASER ROOM
IAQ LEVEL: HIGH

\*It is compulsory to wear Mask during operation.

. Peel off one side of protective layer completely on the acrylic before laser cutting



#### **Safety Documentation**

Fill in the breakdown/faulty report form located nside the laser section if the machine breaks down or stops working while you are using it

Singapore University of Technology & Design  Fabrication Lab		
	Breakdown / Faulty Re	port Form
Name (In Block):	Anne er en	Contact No:
Staff/Student ID:		Pillar/Dept:
<u>s/N</u>	Machine Description	Fault /Breakdown Cause
01		
02		
03		
Date:		Signature:
Date:		Signature: